MAGNISCREEN

NOT ENOUGH SPACE BETWEEN THE WINDOWSILL AND THE WINDOW FURNITURE AT THE BOTTOM OF THE WINDOW?

→ You need at least 12 mm



Magniscreen can adjust the screen to still be effective and neat







MAGNI SCREEN
magnetic insect screens